



Australian Firewood
Order online at
www.australianfirewood.com.au

How to Use Guidelines

Lounge Combustion Heater

SmartBurn Placement

- Place SmartBurn flat and level towards the front corner. By keeping the SmartBurn level the ingredients remain in the casing. If using 2 SmartBurns place them on opposite sides of the heater at each front corner
- Keep the SmartBurn flat and level at all times by sitting it in a little ash or on a fire brick



How many SmartBurns do I need in my Combustion Heater?

- One SmartBurn is suitable for small to medium sized heaters (under 18sq, 180m² heating area, 18kW or 1800sq ft)
- Two SmartBurns will be more effective in medium to large heaters (over 18sq, over 180m² heating area over 18kW or over 1800sq ft). This extra SmartBurn is needed to cope with the increased wood load and heater space
- Two SmartBurns will also be more effective in situations where you have a flue with a bend, a long chimney flue as with a two storey house or considerable existing creosote buildup in the chimney flue
- Each SmartBurn should last up to 3 months

Open Fireplace

SmartBurn Placement

- Place the SmartBurns flat and level on top of the grate at opposite ends of the grate. By keeping the SmartBurns level the ingredients remain in the casing
- If the grate on your open fireplace doesn't allow for the SmartBurns to be kept level, place them under the grate towards the middle of the fire



How many SmartBurns do I need in my Open Fireplace?

- Two SmartBurn units are recommended to cope with the increased wood load, heater space and open heating environment unique to open fireplaces
- Each SmartBurn should last up to 3 months

Kitchen Wood Stove

SmartBurn Placement

- Sit SmartBurn in the "ash pan" compartment, on a small fire brick to prevent the ends from being covered in ash
- It is not recommended that the SmartBurn be placed inside the firebox as the higher temperatures generated in this style of stove will prematurely exhaust the ingredients



How many SmartBurns do I need in my Kitchen Wood Stove?

- One SmartBurn unit
- Each SmartBurn should last up to 3 months

